

PD Series Firmware Change Log

Revision #	Date	Firmware Changes
1.4.5	3/2/2020	Change external pulse trigger from falling edge to rising edge
		Pulse Mode - Add original screen showing flow, SPM and PCT as an option - Default is pulse icon, use arrow keys while running to toggle between old and new screen
		Pulse Mode - Pulse/Stroke option - Setting changed to 1 pulse = X strokes
		Pulse Mode - Pulse/Stroke option - Speed changes to MAX, not editable
		Pulse Mode - Pulse/Stroke option - Calculated fractional strokes accumulate until >1 and extra stroke given
		Pulse Mode - Pulse/Stroke option - Pulses Accumulate to a max of X, where X is 1 Pulse = X Strokes
		Pulse Mode - Pulse/Stroke option - Accumulated stroke will continue after last pulse received (not if pump is stopped)
1.4.3	4/25/2019	Change Pulse Mode screen to pulse icon, removed SPM and PCT - Icon flashes in time to pulse
1.4.2	1/12/2019	Pulse Mode - Addressed issue that could result in an extra stroke